

6147 Transition between Curbed and Non-curbed Roadways

(This section last updated 07-02-15)

When a letdown flume is needed, refer to the scour protection details shown on [DR-401](#).