



- ① Runout curb in 10.0'
- ② End of Taper Details see Typical Detail 7101
- ③ End earth shoulder at the end of the curb transition when no flume is needed.

## TRANSITION BETWEEN CURBED AND NON-CURBED ROADWAYS