

Top of intake may be poured in the field or precast. For precast units, place a 1 inch diameter X 3 inch deep alignment hole 3 inches from each side of the corners of the unit.

1 Four #6 X 9 inch alignment pins (precast tops only).



5t1