

Construct boxout with Class C concrete. Minimum 2 inches clear on reinforcement. Center casting within boxout area.

- 1) 4 foot 8 inch (typ.) #4 bar. Place at mid-slab.
- (2) If boxout is constructed prior to placement of HMA overlay or final lift of HMA pavement, boxout may be constructed low and then final lift or overlay placed.
- 3 Apply tack coat.
- 4 #4 hoops (variable length). Place at mid-slab.

