



- ① Install wattle along contour of slope.
- ② Turn ends of wattle uphill to prevent water from flowing around ends.
- ③ Space stakes at 4 ft. max. Install additional stakes as necessary to prevent movement and undermining.
- ④ Abut ends of adjacent wattles tightly. Wrap joint with 36 in. wide section of silt fence and secure with stakes.

FIGURE: 9040.5 SHEET 1 OF 1

	REVISION NO. ---
	REVISION DATE 10/17/06
FIGURE: 9040.5	
SHEET 1 OF 1	
WATTLE	