



Top of intake may be poured in the field or precast. For precast units, place a 1 inch diameter X 3 inch deep alignment hole 3 inches from each side of the corners of the unit.

1 Four #6 X 9 inch alignment pins (precast tops only).

2 12 inch minimum wall height above all pipes.





NOTE: ALL DIMENSIONS SHOWN OUT TO OUT. D = PIN DIAMETER

(4 bars required)

(4 bars required)