


PERSPECTIVE VIEW

- ① 2 in. x 8 in. pressure treated lumber. Ensure top of spreader is level. Adjust as necessary during construction to maintain spreader in a level condition.
- ② Grade as required to prevent flow around the ends of spreader.
- ③ Length and width as specified.



CROSS SECTION

 <b>SUDAS</b>	REVISION NO. ---
	REVISION DATE 10/17/06
<b>FIGURE: 9040.9</b>	SHEET 1 OF 1

LEVEL SPREADER