# ROTATIONAL CAPACITY TEST

### Long Bolt Procedure

Procedure is required by Article 2408.39 and further described in Materials IM 453.06B. (Photos taken by Bill Burns, Iowa DOT.)

### REQUIRED MATERIAL:


- Calibrated Tension Measuring Device
- Torque Wrench and Spud Wrench
- Washers and/or Shims
- Fasteners from same R-C Lot number

#### STEP 1.



Mark the 3rd through 5th full threads from the shank of the bolt.


### STEP 2.




Install bolt into the Skidmore.

STEP 3.

Install the required number of washers and/or shims to just cover the 3rd, but not more than the 5th thread. (As marked in Step 1. (Must have 1 washer under the nut.)




## STEP 4.




Tighten nut to Snug Tight. (IM 453, Table A-1)

STEP 5.




Match-mark the bolt tip, nut,and base plate.

# STEP 6.




"Zero" torque wrench.

STEP 7.



Tension bolt to at-least value given in IM 453, Table A-2.


### STEP 8.




Record torque tension from Step 7 on R-C Worksheet.

## STEP 9.

Match-mark socket to base plate. (Use Turn-of-Nut rotation amount.) IM453, Table A-3



## STEP 10.



Rotate nut the required Turnof-Nut amount. (IM 453, Table A-3.)

# STEP 11.

